


STANDARD TELECASTER 0135102

CONTROL & SWITCH FUNCTION



3 WAY SWITCH POSITION			
			← 3 WAY SWITCH POSITION
			← NECK PICKUP
			← BRIDGE PICKUP
	PICKUP IS ON		
			PICKUP IS OFF

